

FIG. 1




FIG. 1A






FIG. 2




Temperature
FIG. 3




Phases, Position #10

FIG. 4




In-Plain Strains, Position #10

FIG. 5




In-Plane Stress

FIG. 6




Temperature

FIG. 7




Phases, Position #1

FIG. 8




In-Plain Strains, Position #1

FIG. 9




In-Plain Strains, Position #1

FIG. 10




In-Plane Stress

FIG. 11




Temperature

FIG. 12




Phases, Position #1

FIG. 13




Phases, Position #1

FIG. 14



In-Plain Strains, Position #1

FIG. 15



In-Plane Stress

FIG. 16




FIG. 17





FIG. 18



WARPAGE (OUT OF FLATNESS) OF SPRAYED METALLIC PLATE
VS. STEADY STATE SPRAY TEMPERATURE

FIG. 19